

국제공인교정기관
(액체,기체 유량분야)

Instruction Manual

Vortex Flow Meters


KTVP, KTV Series



– Contents –

System Alarm -----	1
System Menu -----	1
1.System check -----	2
2.Flow unit setting-----	2
3.Reset totalizer -----	2
4.1.System Setup (Water) -----	3
4.2.System Setup (Setam) -----	4
5.1.Calibration Setup ----- (Temperature, Pressure, System Zero)	5
5.2.Calibration Setup ----- (Current output, correction factor)	6
6.Password setting -----	7
7.Wiring ----- (4-20mA,Pulse,RS-485)	8~10
Appendix(RS-485)	

*. System Alarm



1: The running status of meter. If the system of meter is working well, it displays "OK". Otherwise it displays "ERR".

2: Indicator of temperature. If the system of meter is abnormal or the temperature is manually set, it displays "ST". If they are temperature sensors and the temperature sensors are working well, it will be blank. (The temperature range is $-50^{\circ}\text{C} \sim +300^{\circ}\text{C}$)

3: Indicator of pressure. If the system of meter is abnormal or the pressure is manually set, it displays "SP". If it is pressure sensor and the pressure sensor is working well, it will be blank. (The absolute pressure range is 50KPa - 20000KPa)

4: Indicator of operation parameters overflow. If the operation parameters overflow, it displays "OV". If the system of meter is working well, it will be blank. (Overflow includes the parameters which can't be negative are negative, the parameters which can't be zero are zero, and parameters beyond the indication range.)

5: Indicator of current output overflow. If the current output overflow, it displays "mA". If the current output is normal, it will be blank.

6: Indicator of running modes. It displays the battery voltage in battery mode, displays "=" in two-wire current mode, and displays "≡" in three-wire mode.

7: Flow rate. The maximum value is 9999 999.

8: Total flow. The maximum value is in 8 bits, and if total flow is more than 8 bits, it will display 9999 9999.

9: Temperature. If the internal setting is manually set, it displays the setting temperature. Otherwise it displays the temperatures which are collected by the temperature sensors on-the-spot.


10: Pressure. If the meter is set in manual mode, it displays the setting pressure. Otherwise it displays the pressure which is collected by pressure sensor on-the-spot.

Main menu


-- Main menu --

1. Self-test
2. Display unit
3. Total reset
4. Setup
5. Calibration
6. Password


Introduction to flow screen




1. System check




2. Flow rate/totalizer flow Unit setting




3. Reset totalizer




4.1 Setup (Water)




4.2 Setup (Steam)




5.1 Calinbration (Temperature, pressure, Zero) Setup



5.2 Calibration (Current outputCorrection factor,)Setup



6. Password




Move the cursor




Next screen



Change numbers and settings




7. Wiring




Terminal block

7.1 Current output




2-Wire Current output wiring




3-Wire Current output wiring

7.2 Pulse



4-Wire Pulse output wiring

7.3 RS-485



Vortex Flowmeter Communication Protocol

(MODBUS-RTU)

Command:03

Floating point:IEEE-754,;Endianness:3-4-1-2

Holding register:

40001 - 2 : Floating point, Medium temperature(°C) ;
 40003 - 4 : Floating point, Medium pressure(KPa) ;
 40005 - 6 : Floating point, Frequency(Hz) ;
 40007 - 8 : Floating point, Flow (Nm3/s) ;
 40009 - 10 : Floating point, Total of more than one hundred (1234) ;
 40011 - 12 : Floating point, Total of less than one hundred (87.89) ; Total =
 $1234 \times 100 + 87.89 = 123487.89$;
 40013 - 14 : Up Limit alarm ;
 0001 - operator flow;
 0004 - flow;
 0010 - pressure;
 0040 - temperature ;
 40015 - 16 : Down Limit alarm
 0001 - operator flow;
 0004 - flow;
 0010 - pressure;
 0040 - temperature ;
 40017 - 18 : Floating point, 4 - 20mA current output ;
 40019 : Reserve
 40020 : Reserve

국제공인교정기관
(액체,기체 유량분야)

- 한국유량계공업(주) -

인천광역시서구원창로64번길40(원창동)/ 대표전화032-584-5301
대표팩스032)584-5351

Website:<http://www.kometer.co.kr> / e-mail:info@kometer.co.kr