



Ver. PM-TS800EN-12/2022

# **Table of Contents**

1	Intr	oduction	4					
	1.1	General information for the user	4					
	1.2	Limited warranty and disclaimer	4					
	1.3	Requirement for safety 5						
	1.4	Certificate 5						
	1.5	Basic safety instructions for use in Ex area	6					
	1.6	Conditions to maintain intrinsically safety (Ex i)	6					
2	Pro	duct Description	7					
	2.1	Function	7					
	2.2	Features	7					
	2.3	Options	7					
	2.4	Applications	7					
	2.5	Label	8					
	2.6	Product Code	9					
	2.7	Specifications	10					
	2.8	Structure	11					
		2.8.1 External structure	11					
		2.8.2 Internal structure	12					
	2.9	System configuration	13					
	2.10	Principle of operation	13					
	2.11	Product Dimension	14					
		2.11.1 TS800 standard type	14					
		2.11.2 TS800 with limit switch type	14					
		2.11.3 TS800 feedback shaft connection	14					
3	Inst	tallation	15					
	3.1	Before installation	15					
	3.2	TS800L installation	15					
		3.2.1 Notes on installation	15					
		3.2.2 Effective rotation angle range of feedback lever	16					
		3.2.3 Lever type and dimension	16					
		3.2.4 Bracket Installation	17					
		3.2.5 Dimension after installation	17					
	3.3	TS800R installation	18					
		3.3.1 TS800R installation examples	18					
		3.3.2 TS800R bracket installation components	18					
		3.3.3 TS800R installation steps	19					
	3.4	TS820 Remote type installation	21					
	3.5	Option module Installation	22					

		3.5.1 Position transmitter module Installation	22
		3.5.2 HART communication module Installation	22
		3.5.3 Limit switch module Installation	23
		3.5.4 How to adjust limit switch cam	24
	3.6	How to adjust Auto/Manual switch	25
	3.7	Orifice installation	26
4	Pn	eumatic connection	27
	4.1	Supply air pressure condition	27
	4.2	Pneumatic port Description	27
	4.3	Air connection	28
		4.3.1 TS800L air connection	28
		4.3.2 TS800R air connection	28
5	Ele	ectrical connection	29
	5.1	Terminal description	29
	5.2	Wiring diagrams	30
		5.2.1 Power and Feedback signal connection	30
		5.2.2 Limit switch connection	30
		5.2.3 Alarm signal connection	30
6	Ca	libration	31
	6.1	LCD description	31
	6.2	Button description	32
	6.3	How to quickly perform Auto calibration	33
		6.3.1 Auto calibration Steps	33
	6.4	Software map	34
	6.5	Main menu Description	35
	6.6	Main parameter menu Description	36
	6.7	Submenu Description	37
		6.7.1 TUNNING	37
		6.7.2 PARAMETE	39
		6.7.3 DEVICE P	41
		6.7.4 INFOMATN	44
		6.7.5 DIAGNOST	45
		6.7.6 EMERGNCy	48
7	Err	6.7.6 EMERGNCy or code and Troubleshooting	48 49
7	<b>Err</b> 7.1	-	

# 1 Introduction

### 1.1 General information for the user

This instruction includes installation, operation, maintenance, and parts information for Tissin TS800 Valve Positioner. Keep these instructions in a location which is easily accessible to every user and make these instructions available to every new owner of the device.□

- Installation, commissioning and maintenance of the product can only be performed by trained specialist personnel who have been authorized by the plant operator to do so.
- Before installing or commissioning, be sure to read and thoroughly understand the product manual and operate the product properly.
- Operators must strictly observe the applicable national regulations with regards to installation, function tests, repairs, and maintenance of electrical products.
- Only trained and authorized person should operate the machinery and the equipment.
- Do not use this positioner out of the range of its specifications as this can cause failure.
- Do not service or attempt to remove product and machinery/equipment until safety is confirmed.
- Never handle mechanical equipment or disassemble the device until safety is confirmed.
- Before loosening the pneumatic lines and valves, turn off the pressure and vent the pneumatic lines.
- Observe applicable accident prevention and the safety regulations for electrical equipment.

The manual can be altered or revised due to hardware of software upgrades without any prior notice. Please visit our website ( www.tissin.co.kr ) and check the latest documentation.

### 1.2 Limited warranty and disclaimer

- This product has been fully inspected and shipped through a thorough quality inspection procedure. The manufacturer warranty period of the product is 18 months after the product is shipped from Tissin in Korea.
- For any failure or damage reported within the warranty period which is clearly our responsibility, a replacement product or necessary parts will be provided. This limited warranty applies only to our product independently, and not to any other damage incurred due to the failure of the product.
- Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using under unqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

### 1.3 Requirement for safety

This manual contains notices you have to observe in order to ensure your personal safety, as well as to prevent damage to property. These safety instructions are intended to prevent hazardous situations and/or equipment damage. For the safety, it is important to follow the instructions in the manual.

# 

Failure to observe the warning may result in serious injuries or death.

# 

Failure to observe this warning may result in damage to the device or personal injury.

# 

Failure to observe the warning may result in damage to the device or may degrade performance.

### 1.4 Certificate

This product has obtained a variety of explosion-proof certification and safety level certification. For details, please visit our website and download the corresponding explosion-proof certificate for confirmation.

Certi	fication	Certificate number	Explosion proof grade	
IECEx	IECEx	IECEx EPS 17.0088X	Ex ia IIC T5/T6 Gb Ex ia IIIC T100℃/85℃ Db IP66	
(Ex)	ATEX	EPS 17 ATEX 1 174 X	II 2G Ex ia IIC T5/T6 Gb II 2D Ex ia IIIC T100℃/85℃ Db IP66	
EHE	EAC	RU C-KR.АД07.В.01840/20	1Ex ia IIC T5/T6 Ga X	
۶ ک	KCS	20-KA2BO-0188X	Ex ia IIC T6/T5	
ي	RUS	20-KA2BO-0189X	Ex ia IIIC T85℃/100℃	
	ссс	2020322307002407	Ex ia IIC T5/T6 Gb	
Ex NEPSI	NEPSI	GYJ18.1239X	Ex ia IIIC T85°C/T100°C Db	
SIL SIL		FS/71/220/19/0378 (SGS TUV SAAR)	SIL2 at HFT=0 SIL3 at HFT=1	
	CSA	801369740	Class I, Div2, Groups A,B,C,D; T5T6 Ex ib IIC T5T6 Gb Class I, Zone 1 AEx ib IIC T5T6 Gb Class II, Div2, Groups E,F,G; T100°CT85 Class III Ex ib IIIC T100°CT85°C Db Zone 21 AEx ib IIIC T100°CT85°C Db	

### **1.5** Basic safety instructions for use in Ex area

To prevent the risk of explosion, observe not only the basic safety instructions in the respective operating instructions for operation in the Ex area, but also the following.

# 🚹 WARNING

- Observe the applicable safety regulations (also national safety regulations) as well as the general rules of technology for construction and operation.
- Make sure that the device is suitable for the area of use.
- Check the positioner's certified and permitted explosion proof range.
- Close all unnecessary Cable Gland with the locking screws approved by the explosion site.

### **1.6** Conditions to maintain intrinsically safety (Ex i)

 Make sure to connect "Intrinsic safety" type protection device to intrinsically safe circuit only.

WARNING

- Observe the specifications for the electrical data on the certificate and in technical data.
- In order to maintain intrinsically safe protection, be sure to use a barrier that meets the following specifications.

Barrier specifications	Ui	li	Pi	Ci	Li
Main power	28V	101mA	707mW	0.6nF	6uH
Position transmitter, Alarm1, Alarm2, Limit Switch(Dry contact type)	28V	101mA	707mW	0.6nF	6uH
Limit Switch (Proximity type)	16V	26mA	34mW	30nF	50uH

## 2 **Product Description**

### 2.1 Function

Smart valve positioner TS800 series controls the valve stroke in response to an input signal of 4~20mA DC from the control panel, DCS or calibrator.

### 2.2 Features

- LCD and 4 button local control
- Quick and easy calibration
- PST and alarm function
- Auto/Manual switch included
- Built-in self-diagnostic function
- Modularization of the internal parts
- IP66 / NEMA4X
- Improvement of valve control speed by applying large flow pilot valve
- Strong vibration resistance and impact resistance

### 2.3 Options

- Position transmitter (4~20mA DC Feedback signal)
- HART communication (Ver. HART 7)
- Limit switch (Mechanical or Proximity type)
- Remote control type (TS820)

### 2.4 Applications

The TS800 is mounted on a pneumatic control valves and is used for fluid control of industrial parts.

- Oil and gas
- Chemicals
- Power plant
- Paper
- Water treatment
- Pharmaceutical
- Printing and dyeing processing
- Food and beverage
- Etc.

# 2.5 Label

SMART POSITIONER						
MODEL No.		<b>C</b> s	Ex			
SERIAL No.		20-KA2BO-0188X	GYJ18.1239X			
OPERATING TEMP.		20-KA2BO-0188X 20-KA2BO-0189X	G1J10.1239X			
EXPLOSION PROOF	Ex ia IIC T5/T6 Gb Ex ia IIIC T100°C/T85°C Db IP66		Œ			
EXPLOSION PROOF TEMP.	T5 : −40℃ ~ +60℃ T6 : −40℃ ~ +40℃	IECEX EPS 17.0088	2004			
WEATHER PROOF	IP66		<u> </u>			
INPUT SIGNAL	4~20mA DC					
SUPPLY PRESSURE	0.14 ~ 0.7MPa (1.4 ~7 bar)	l ž	9224U			
Ui, Ii, Pi, Ci, Li,	See Certificate		1 202			
#397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea						
	Made in Korea	τ	155 <b>in</b>			

Item	Description
MODEL No.	Indicate the model number.
SERIAL No.	Indicate the serial number.
EXPLOSION PROOF	Indicate the certified explosion proof grade.
OPERATING TEMP.	Indicate the allowable operating temperature.
EXPLOSION PROOF TEMP.	Indicate the ambient temperature range for the explosion proof. This temperature range must be observed when using in explosion-proof areas.
WEATHER PROOF	Indicate the enclosure grade.
INPUT SIGNAL	Indicates input current signal range.
SUPPLY PRESSURE	Indicate the allowable input supply pressure range.
Ui, Ii, Pi, Ci, Li	Indicate required barrier specification for intrinsically safety circuit configuration. Please refer to the certificate for the detailed specifications.

# 2.6 Product Code

		TS800							
Model	Standard type	TS800							
	Remote type	TS820							
	Stainless steel	TS805							
	316 type								
Acting type	Linear type		L						
	Rotary type		R						
Explosion proof type	Non-explosion p	oof		Ν					
(Jpc	Ex ia IIC T5/T6			A					
Connection type*	Conduit entry	<u>Air o</u>	conne	<u>ction</u>					
	G(PF)1/2	PT1	/4		1				
	G(PF)1/2	NP	Г1/4		2				
	NPT1/2	NP	Г1/4		3				
	M20	NP	Г1/4		4				
	M20	G1/	4		5				
Lever type	10~80mm					1			
(Linear)	70~150mm					2			
	Adapter type (70	)mm)				3			
Lever type	M6 x 39L (Fork lever type) 1								
(Rotary)	NAMUR 5								
Ambient Temp.	-30°C∼ +85°C (S	tandard ty	pe)				S		
(Non-explosion proof)	-40°C∼ +85°C L								
	-60°C~ +85°C (for Russia EAC certification) U								
Communication	None							0	
	Position transmit	tter (4~20ı	mA D0	C feed	back)			1	
	HART communio	cation						2	
	HART and Posit	ion transm	nitter (	4~20n	nA DC	feedl	back)	3	
Limit switch	None					0			
(For TS800/TS805)	Mechanical type (Dry contact NO, NC, COM)					Μ			
	Proximity type (F	P+F NJ1,5	-F-N)						Ρ
	With Dome cover (Without Limit switch)						D		
Cable length	5m					1			
(For TS820) 10m					2				
	User define (Les	s than 20	meter	s)					Х

## 2.7 Specification

Model		TS800	TS805		
Input sign	al	4~20mA DC			
Impedanc	e	500Ω (20mA DC)			
Supply pr	essure	0.14~0	).7MPa		
Stroke		10~150mm(Linear typ	e), 0~90º(Rotary type)		
Air conne	ction	PT1/4, NPT1/4, G1/4	NPT1/4		
Gauge co	onnection	PT1/8, NPT1/8	NPT1/8		
Conduit		G(PF)1/2, NPT1/2, M20	G1/2		
Evolosion	proof type	II 2G Ex ia I	IC T5/T6 Gb		
Explosion	i proor type	II 2D Ex ia IIIC T1	00℃/85℃ Db IP66		
Enclosure	)	IP66 (EN60529)			
	A ating Tanan	-30℃~+85℃(Standard type),			
Ambient	Acting Temp.	-40°C∼+85°C(Low temp type)			
Temp.	Explosion proof Temp.	-40°C~ +60°C(T5) / -40°C~ +40°C(T6)			
Linearity		±0.5% F.S.			
Sensitivity	/	±0.2% F.S			
Hysteresi	s	±0.5% F.S			
Repeatab	ility	±0.3% F.S			
Air consu	mption	Below 2.3LPM (Sup.=0.14MPa)			
Required	air quality	Class 3 (ISO8573-1)			
Flow capa	acity	Over 100LPM (Sup.=0.14MPa)			
Material		Aluminum die cast	Stainless steel 316		
Weight		2.2kg	4.2kg		
		=:=::9			

## **Option specification**

Option	Item	Specification
HART	HART version	HART 7
Position transmitter	Wire connection type	2 Wires
Position transmitter	Supply voltage	10~30V DC
Lingit gyuitala	Mechanical type	AC125V, 3A, DC30V, 2A
Limit switch	Proximity type	DC8.2V 8.2A

Note: Please contact our sales department for other specifications.

### 2.8 Structure

### 2.8.1 External structure



Note: Only Limit switch type product is equipped with Dome indicator.

### 2.8.2 Internal structure



- ① Pilot valve
- 2 Potentiometer
- ③ Pressure sensor (Option)
- ④ Torque motor
- 5 Main PCB
- 6 Terminal block
- ⑦ HART communication module (Option)

- (8) Position transmitter module(Option)
- 9 Buttons
- 10 Alarm signal connection terminal
- ① PCB cover
- 2 Limit switch connection terminal
- Limit switch (Option)

### 2.9 System configuration

Basically, the control valve system consists of a positioner for controlling the pneumatic pressure of the actuator, an actuator for controlling the opening of the valve, and a valve for controlling the flow of the fluid.



### 2.10 Principle of operation

TS800 receives 4-20mA input signal of the control room, micro-processor (CPU) compares input signal with position feedback through potentiometer and sends control signal to I/P conversion module torque motor, torque motor converts it to a pneumatic signal to controls pilot valve to controls the opening of the control valve by converting output pressure of OUT1 and OUT2.



tissin

### 2.11 Product Dimension

### 2.11.1 TS800 standard type



### 2.11.2 TS800 with limit switch type



### 2.11.3 TS800 feedback shaft connection



# 3 Installation

### 3.1 Before installation

### MARING

- Make sure if TS800 is appropriate to the valve and actuator installation conditions and the site requirements specifications before installation.
- If the installation state is not correct, TS800 control characteristics may be degraded.

### 3.2 Linear type installation

### 3.2.1 Notes on installation

When make the mounting bracket and connecting the lever to the stem connection pin, be sure to observe the following two points.

If failure to observe the followings, it will affect the product performance such as linearity.

#### 

- ① When the valve stroke is 50%, the feedback lever should be horizontal.
- ② When the valve stroke is 50%, the stem connection pin must be located at the numeric position marked on the feedback lever that is corresponding to the valve stroke.



- ① Feedback lever
- ② Stem connection pin
- ③ Pin fixing spring

- ④ Actuator stem
- (5) Valve opening indicator

### 3.2.2 Effective rotation angle range of feedback lever

The effective rotation angle of TS800L lever is respectively 30° upward and downward that is based on horizon.

Follow 3.2.1 notes, effective rotation angle can be maintained to achieve the best performance.

### 

- If the rotation angle range is too small during operation, the performance of products such as linearity may be degradation.
- If the rotation angle range is too big during operation, may damage the product or cause malfunctions.



### 3.2.3 Lever type and dimension

The numeric positions marked on the feedback lever correspond to the valve stroke, and the stem connection pin must be connected to the corresponding marked location.

Lever No.	Valve stroke	Dimensions
No.1	10~80mm	
No.2	70~150mm	
No.3	10~70mm For the tube less type actuator	

#### 3.2.4 **Bracket Installation**

Refer to the TS800L drawing (refer to 2.11.1) and actuator drawing, please make appropriate bracket and install the positioner on the actuator.



#### 3.2.5 **Dimension after installation**



<Lever No.1 or 2 >

- ① Stem connection pin
- Feedback lever (2)
- ③ Bracket

- ④ Actuator york
- (5) Lever adapter

### 3.3 Rotary type installation

### 3.3.1 Rotary type installation examples



<Fork lever type>

<NAMUR type>

### 3.3.2 Rotary type bracket installation components

When shipped from the factory, components No.1~8 are provided as standard. The brackets support the NAMUR mounting standard (VDI/VDE3835, IEC60534-6-2).



### 3.3.3 Rotary type installation steps



# Smart valve positioner TS800/TS805 Series

# tissin



### 3.4 TS820 Remote type installation

The TS820 is designed cable to the sensor part and the main body, it is designed to transmit the change of the stem position of the valve to the body through the potentiometer built in the sensor.

### Application site

- Where the valve is located at a high or inaccessible location.
- High temperature environment. (over than 85° degrees) (Non-explosion proof model only)
- Large vibrating lines.

### Installation

- ① Install the sensor part on the valve, and install Main body on the accessible places.
- (2) Please follow the installation instructions of TS800L or TS800R for the sensor part's installation.
- ③ The sensor part and Main body are connected via cable, the length of cable must not over 20M.
- ④ Pneumatic piping should connect the OUT port of Main body to the actuator.



### 3.5 Option module Installation

According to the site requirements, the following modules can be purchased separately and installed. The corresponding function can be realized by installing modules, and the modules do not affect each other.

X Please cut off the input power and install the modules.



<Position transmitter module>



<HART communication module>

### 3.5.1 Position transmitter module Installation

Open the body cover and PCB cover, and install the position transmitter module to the main PCB as figure below.



- Be sure to set feedback zero point setting and end point setting once after installed the feedback module. Please refer to page38 OUT ZERO and OUT END setting method.
   Please connect 5 lumper when you install PTM module.
- Please connect 5Jumper when you install PTM module.



### 3.5.2 HART communication module Installation

Open the body cover and PCB cover, and install the HART communication module to the main PCB as figure below.

※ Please disconnect SJumper when you install HART module or install HART and PTM both.



### 3.5.3 Limit switch module Installation

There are two types of limit switch, mechanical and proximity type.



<Mechanical type module>



<Proximity type module>

### Installation steps

- 1 Open the cover.
- 2 Mount the limit switch module in PCB protective cover groove and fix with fixing bolts.
- ③ Turn the camshaft and mount it to the main shaft.
- ④ Fix the camshaft with fixing bolts.
- (5) Mount the dome indicator to the camshaft.



### Note

Standard product does not have a dome indicator sight window. The cover for limit switch product must also be replaced.

### 3.5.4 How to adjust limit switch cam



The cam position is set at the factory. If you want to change the cam position, please follow the steps below.

- ① Open the cover and separate the dome indicator by referring to the above figure.
- 2 Loosen the fixing bolt slightly with a Phillips screwdriver, but do not separate it.
- ③ Adjust cam 3 and 4 by referring to the following figure below, and adjust the angle so that the switch operates at the position you want.
- ④ After adjusting the angle, fasten the fixing bolt tightly.



### 3.6 How to adjust Auto/Manual switch

#### 

- Please be careful as the valve moves when you operate Auto/Manual switch.
- The input air pressure is directly transmitted to the actuator when you switch to manual mode, so do not exceed permissible air pressure range.



Description	<ul> <li>Auto/Manual switch acts as a bypass valve.</li> <li>If set to Auto, the positioner controls the valve opening.</li> <li>If set to Manual, regardless of signal from the positioner, the supply pressure input from the regulator is transmitted directly to the actuator.</li> </ul>
Purpose	<ul> <li>When Control valve fails, set to Manual mode and adjust the output pressure of the regulator, if the valve moves with the pressure change, there is a high possibility that the positioner has a problem. But if the valve does not move, there is a high probability that the valve has failed.</li> <li>You can adjust the valve opening with the regulator by switching to Manual mode in case of product installation or field emergency. (It works only in single acting type product)</li> </ul>
Adjustment method	<ul> <li>If turns Auto/Manual switch fully clockwise with a slotted screwdriver, it sets to Auto mode, i.e. the positioner controls the valve.</li> <li>If turns Auto/Manual switch counterclockwise a few times with a slotted screwdriver, it sets to the Manual mode, i.e. the regulator's air pressure is transmitted directly to the actuator.</li> </ul>
Notes	The product is set to Auto mode at the factory.

### 3.7 Orifice installation



<Orifice>

### Purpose

A normal action product does not need to install the orifice, but if the hunting phenomenon occurs after installation on a small actuator, it can be solved by installing an orifice to reduce the output flow of air pressure transmitted to the actuator from the positioner. The hole size of the orifice is 1mm.

### How to install

As figure below, Insert the orifice into OUT1 port, and fix it by turning it all the way with a slotted screwdriver

- When using for single type actuator, please install orifice to OUT1 port only.
- When using for double type actuator, please install orifice to both OUT1 and OUT2 ports.



### Note

Please contact us, if you need any of the above parts.

# 4 **Pneumatic connection**

### 4.1 Supply air pressure condition

### 

- Use only dehumidified and dust-extracted compressed clean air.
- The air pressure input must be equipped with a regulator to supply constant air pressure.

## 4.2 Pneumatic port Description



### 4.3 Air connection

 This product is designed to increase the air pressure of OUT1 as 4 ~ 20mA current input signal increases.

NOTICE

∕∖

### 4.3.1 TS800L air connection



### 4.3.2 TS800R air connection



# **5** Electrical connection

# 

- Be sure to always check that the electrical load is within the stated range on the label. Exceeding the rating might cause a malfunction to circuit boards or burn out electrical components.
- Check polarity of + and exactly and connect wires.

## 5.1 Terminal description



- ① Input signal (+)
- ② Input signal (-)
- ③ Internal ground
- ④ Feedback signal (+)
- (5) Feedback signal (-)

- 6 Alarm1 signal (+)
- ⑦ Alarm1 signal (-)
- (8) Alarm2 signal (+)
- 9 Alarm2 signal (-)
- 10 External ground bolt
- (1) Conduit

### 5.2 Wiring diagram

### 5.2.1 Power and feedback signal connection



### 5.2.2 Limit switch connection



### 5.2.3 Alarm signal connection

The alarm module is built in to all products. According to the requirements of the site, you can get the feedback from the emergency alarm signal by wiring as follow.



tissin

# 6 Calibration

## 6.1 LCD description



No.	Displayed contents	Description				
1	Menu information	Displays the running menu. (Main menu, Main parameter, Sub parameter)				
2	Menu's value	Displays t	he present parameter value of the menu.			
3	Menu's value unit	Displays t	he present menu's value unit.			
		PV	Progress value			
4	Menu's value separator	SV	Signal value			
-	Sopulation	MV	Motor control value			
5	Progress bar	Displays t	he progress of the processor in bar form.			
6	Main parameter	Displays the currently selected main parameter.				
7	Parameter bar	Displays the position of the selected main parameter.				
8	Alarm 1	The icon is displayed, when the set value of alarm 1 is satisfied.				
9	Alarm 2	The icon is displayed, when the set value of alarm 2 is satisfied.				
10	HART communication	The icon is displayed, when HART communication is in progress.				
(11)	Error code	The icon is displayed If there is an error during calibration or operation.				
12	Modifying	The icon is displayed when changing the internal setting values such as parameter modification.				
13	LOCK	The icon is displayed when the program is locked.				
(14)	UNLOCK	The icon is displayed when the program is unlocked.				

# 6.2 Button description



Button	Description
ENTER	<ul><li>Execute the functions of the selected menu.</li><li>Saving the modified parameter values.</li></ul>
ESC	<ul> <li>Moving from the current menu go back to the upper level menu.</li> <li>Cancel current command.</li> </ul>
UP	<ul> <li>Moving between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change to the larger value of the set value of the selected parameter.</li> </ul>
DOWN	<ul> <li>Moving between menus of the same level such as main menu, main parameter, sub parameter.</li> <li>Change to the smaller value of the set value of the selected parameter.</li> </ul>

### 6.3 How to quickly perform Auto calibration

Open the cover of the product and follow below steps to perform Auto calibration.

- ① Please input current signal **18mA**, then press **<UP>** button for 3 seconds.
- 2 The positioner automatically performs Auto calibration.
- ③ Auto Calibration is performed sequentially from STEP 1 to 7 on LCD, and may take 2-5 minutes depending on the valve size.

Ŵ	NO	ΓΙϹΕ
---	----	------

• If an error occurs during Auto calibration, please refer to Error codes on page 49 to 50.

### 6.3.1 Auto calibration Steps

When you progress auto calibration, it automatically proceed in the following steps below.

Steps	Description
STEP0	Check ZERO point of the valve speed. Checked at the reference point of valve stops.
STEP1	Find ZERO point of the valve stroke.
STEP2	Find END point of the valve stroke.
STEP3	Measure the valve fully close time. Measure the time of the valve takes from full open to full close.
STEP4	Measure the valve fully open time. Measure the time of the valve takes from full close to full open.
STEP5	Measure Low BIAS Measure the motor signal reference value, when the position of valve at 25%.
STEP6	Measure High BIAS Measure the motor signal reference value, when the position of valve at 75%.
STEP7	Measure maximum error value.

### 6.4 Software map

- To enter Main Parameter menu : Please input 4-20mA current signal and press **<ENTER>** button for 3 seconds after booting up.
- To enter Submenu : Press **<UP>** or **<DOWN>** button to select Main Parameter menu and press **<ENTER>** button.
- To select Submenu : Press **<UP>** or **<DOWN>** button.

Main menu	MAIN LIN	MAIN IN %	MAIN IN mA	MAIN VEL	MAIN DEV	
Main parameter menu	TUNNING	PARAMETR	DEVICE P	INFOMATN	DIAGNOST	EMERGNCy
	AUTO RUN	DEAD bND	ACTU SNG	FIRM VER	ERR CODE	PASSWORD
	AM FULL	KP	ACTU LIN	DEVI REV	AUTO CHK	EMGY NON
	TbL	KI	FORCE OP	HART VER	PST RUN	FULL OP
	VAL OPCL	KD	FORCE CL	POLL ADD	PST CFG	FULL CL
	VAL ZERO	GKP	DAMP	TRAVEL K	PST REDy	STOP
Cubmonu	VAL END	GKI	SPLT ZER	OP TIME	AL1 NONE	UNLOCK
Submenu	OUT ZERO	GKD	SPLT END	CL TIME	AL2 NONE	
	OUT END	KF	COMPENSA	TEMPERAT		
	IN ZERO	KL	ACT NORM	TEMP MAX		
	IN END	RANGE I	OUT NORM	TEMP MIN		
	bIAS25	CHAR LIN	HT NORMR		, ,	
	bIAS75	USER DEF	DSP NORM			

### 6.5 Main menu description

After the product is booted, **<MAIN LIN>** is displayed, which shows the current opening of the valve. Press **<UP>** or **<DOWN>** button to move to the following menu and check the corresponding information.

In Main menu, information such as the valve opening and the magnitude of the input current signal can be checked and the execution of the command or the modification of the parameter value cannot be performed.

Main menu	Description		
	Displayed the percentage of current valve opening value. Depending on the set value of the flow characteristics, one of the following values is displayed.		
	LCD display value	Flow characteristics	
MAIN LIN	MAIN LIN	Linear	
	MAIN EQ1	EQ1 (1/25)	
	MAIN EQ2	EQ2 (1/50)	
	MAIN QO	Quick Open	
	MAIN USR	User defined 17 points	
MAIN IN %	<ul> <li>Displayed the magnitude of input signal that the positioner recognizes as percentage.</li> <li>If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply.</li> <li>If the supply current is normal, please reset <in zero=""> and <in end=""> values in <tuning> of main parameter.</tuning></in></in></li> </ul>		
MAIN IN mA	<ul> <li>Displayed the magnitude of input signal that the positioner recognizes as mA.</li> <li>If the size of the input signal recognized by the positioner differs from output signal of the DCS or calibrator, check the voltage of the power supply.</li> <li>If the supply current is normal, please reset <in zero=""> and <in end=""> values in <tunning> of main parameter.</tunning></in></in></li> </ul>		
MAIN VEL	<ul> <li>Displayed currently operating speed of the valve as numbers.</li> <li>As the value, between -2047 to +2048, negative numbers indicate speed at close, and positive numbers indicate speed at open.</li> <li>0 means stop and the larger the absolute value, the faster the speed.</li> </ul>		
MAIN DEV %	<ul> <li>Displayed the percentage of error between the current input signal and valve opening value.</li> <li>The larger the error, the lower the control characteristic.</li> </ul>		

### 6.6 Main parameter menu Description

Main parameter menu corresponds to main menu in which various parameters are classified by function.

- After the product is booted, press **<ENTER>** button for 3 seconds to enter Main Parameter menu.
- Main parameter menu is classified as below and can be moved by pressing <UP> or <DOWN> button.
- Press **<ENTER>** button in the corresponding menu to enter Submenu.

Main parameter menu	Main function		
TUNNING	<ul> <li>Run Auto calibration.</li> <li>Change Zero and Span of the valve manually.</li> <li>Change Zero and Span of feedback signal manually.</li> </ul>		
PARAMETR	<ul> <li>Set Dead band.</li> <li>Change PID values.</li> <li>Change flow characteristics.</li> </ul>		
DEVICE P	<ul> <li>Set Single/Double according to actuator type.</li> <li>Set Linear/Rotary according to actuator type.</li> <li>Set signal point of Force Open/Close.</li> <li>Set acting type. (Direct Action / Reverse Action)</li> <li>Set the valve acting speed. (DAMP)</li> </ul>		
INFOMATN	<ul> <li>Display the product model.</li> <li>Display the device and HART version.</li> <li>Display Full Open/Close time.</li> <li>Display the current ambient temperature, the recorded maximum ambient temperature, and the recorded minimum ambient temperature.</li> </ul>		
DIAGNOST	<ul> <li>Display the error code.</li> <li>Set PST function.</li> <li>Set Alarm function.</li> </ul>		
EMERGNCy	<ul> <li>Set Password.</li> <li>In case of emergency, set to forcibly open the valve, or close valve, or maintain current position of the function.</li> <li>Set Lock and Unlock function.</li> </ul>		
#### 6.7 **Submenu Description**

The following is a detailed description of Main parameter menu's Submenu.

- Press **<ENTER>** button in Main parameter menu to enter Submenu. Use **<UP>** and **<DOWN>** button to move between Submenu. ٠
- •

#### 6.7.1 TUNNING

Submenu	Description			
AUTO RUN	<ul> <li>Run Auto calibration.</li> <li>Executable from any input signal between 4 and 20 mA.</li> <li>It takes 1~3 minutes, depending on the valve size.</li> </ul>			
	Select Auto calibra	tion mode.		
	Mode	Description		
	AM FULL	Set all parameter values again.		
АМ	AM BIAS	Only reset the motor reference value, but the other parameter values are not modified.		
	AM PIDb	Only reset PID value, but the other parameter values are not modified.		
	AM ZEb R	Only reset End point and Zero point of the valve, but the other parameter values are not modified.		
	Factory setting	AM FULL		
		of product. an be changed when hunting occurs due to a valve stem or a small actuator size.		
	TbL 1 HS	When you want to increase the sensitivity. For example, when the actuator size is small.		
TbL	TbL 2 NS	Normal mode.		
	TbL 3 LS	When you want to lower the sensitivity. For example, when hunting occurs due to the high friction of the valve stem.		
	TbL 4 LLS	When the actuator size is very large.		
	Factory setting	TbL 2 NS		
VAL OPCL		current signal, it performs the function of opening ve with < <b>UP</b> > or < <b>DOWN</b> > button manually.		
VAL ZERO	Reset ZERO point of the valve manually. Input 4mA current, press <b><up></up></b> and <b><down></down></b> button to change the valve position, and press <b><enter></enter></b> button to save the current valve position, then the positioner recognizes the current position as valve ZERO point.			

	-
VAL END	Reset END point of the valve manually. Input 20mA current, press <b><up></up></b> and <b><down></down></b> button to change the valve position, and press <b><enter></enter></b> button to save the current valve position, then the positioner recognizes the current position as valve END point.
OUT ZERO	Reset ZERO point of the feedback signal manually. Input <b>4mA</b> current signal, valve reaches Zero position, after press < <b>UP</b> > or < <b>DOWN</b> > button to adjust the value, until the 4mA feedback signal is output, and then press < <b>ENTER</b> >button to save.
	Please reset <b>OUT ZERO</b> setting after installing feedback module.
OUT END	Reset END point of the feedback signal manually. Input <b>20mA</b> current signal, valve reaches end position, after press < <b>UP</b> > or < <b>DOWN</b> > button to adjust the value, until the 20mA feedback signal is output, and then press < <b>ENTER</b> > button to save.
	Please reset <b>OUT END</b> setting after installing feedback module.
IN ZERO	Reset ZERO value of input signal manually. If < <b>MAIN IN%</b> > and < <b>MAIN mA</b> > displayed at Main menu differ from the actual input signal, conduct the commands of this menu. Input 4mA current at this menu and press < <b>ENTER</b> > button twice to save.
	After replacing the main board or conduct program initialization, please reset <b>IN ZERO</b> setting.
IN END	Reset END value of input signal manually. If <b><main in%=""></main></b> and <b><main ma=""></main></b> displayed in Main menu differ from the actual input signal, conduct the commands of this menu. Input <b>20mA</b> current at this menu and press <b><enter></enter></b> button twice to save.
	After replacing the main board or conduct program initialization, please reset <b>IN END</b> setting.
BIAS25	The reference value of the motor when valve stroke is 25%. It is set automatically during Auto calibration, so please do not modify this parameter value manually.
BIAS75	The reference value of the motor when valve stroke is 75%. It is set automatically during Auto calibration, so please do not modify this parameter value manually.

#### 6.7.2 PARAMETR

Submenu Description					
the problem can be solved by increasing the value wit allowed by the field.	<ul> <li>If hunting or oscillation occurs due to high packing friction of the valve, the problem can be solved by increasing the value within the range allowed by the field.</li> <li>If the value is set too high, the accuracy may be reduced.</li> </ul>				
Factory setting 0.3%					
<ul> <li>P control value, the proportionality constant value of the coprocess of reaching the target point</li> <li>If the setting value increase, the positioner finds the tarbut it is more likely to have hunting.</li> <li>If the setting value decrease, the stability of the positioner finds the target point slowly.</li> </ul>	<ul> <li>P control value, the proportionality constant value of the control signal in the process of reaching the target point</li> <li>If the setting value increase, the positioner finds the target point quickly but it is more likely to have hunting.</li> <li>If the setting value decrease, the stability of the positioner is higher, but positioner finds the target point slowly.</li> </ul>				
	innel e condina 4.				
<ul> <li>I control value, the integral value that adds the correction s the error percentage to the existing correction signal.</li> <li>If the setting value is too high, the time to reach the tal accelerated, but the oscillation phenomenon is easy to If the setting value is too low, it will slow down the sea point.</li> </ul>	rget point is o occur.				
Range 0~500					
<ul> <li>KD</li> <li>KD</li> <li>D control value, indicates the derivative value of the competibased on the percentage of error allowance.</li> <li>If the setting value is too high, it will slow down the sea point.</li> <li>If the setting is too low, the oscillation is likely to occur</li> </ul>	arch for the target				
Range 0~500					
<ul> <li>GKP</li> <li>P control value, the proportionality constant value of the coprocess of reaching the target point</li> <li>The function is the same as KP control value but falls error range of the target value, GKP value is applied in</li> </ul>	within the ± 1%				
Range 0~5.0	_				
<ul> <li>GKI</li> <li>I control value, the integral value that adds the correction s the error percentage to the existing correction signal.</li> <li>The function is the same as KI control value but falls w error range of the target value, GKI value is applied in the second se</li></ul>	vithin the ± 1%				
Range 0~5.0					
D control value, indicates the derivative value of the competition based on the percentage of error allowance.	D control value, indicates the derivative value of the compensation signal				
	within the ± 1%				
	within the ± 1%				
error range of the target value, GKD value is applied in       Range     0~5.0       Control value to overcome valve friction.       Increasing KF value can improve hunting caused by value	within the ± 1% nstead of KD value.				
error range of the target value, GKD value is applied in Range 0~5.0 Control value to overcome valve friction.	within the ± 1% nstead of KD value.				

	Control value to ov Increasing KL				rshootir	ıg prob	lem.		
KL	Range		0~50						
	Factory setting		0						
RANGE I	<ul> <li>Control the maximum control ra</li> <li>If this value is too high, the excessive I value is used, v</li> <li>If this value is too low, the makes I value's control ran to control the position sens</li> <li>Range</li> </ul>			e of Au h is like of Aut smaller ly.	to calib ely to ca o calibr	ration i ause o\ ation is	s incre /ershoo shorte	oting. en. But	it
				~40					
	Factory setting		5						
	Set the characteris	tics of the va	alve	control					
	100		1	Input (mA)	Linear (%)	EQ1 (%)	EQ2 (%)	QO (%)	USER (%)
	-0		1	4	0	0	0	0	0
	80 <sup>30</sup> / <sub>8</sub> 60 Quick Open Parso		/	5	6.25	2.55	1.31	29.13	4
	R wick Ope	sē /		6	12.5	3.26	2.81	46.84	8
	%) 60 Quick US	inest		7	18.75	4.16	4.54	57.21	12
		line		8	25	5.32	6.55	64.56	18
	40	LOP PERSON		9	31.25 37.5	6.79	8.92	70.27	30 40
	20	HOT LOT		10 11	43.75	8.67 11.07	11.73 14.76	74.93 78.87	40 50
				12	43.73 50	14.14	18.26	82.28	59
	0			13	56.25	18.06	22.58	85.29	65
	4 8 1: Inp	2 16 ut (mA)	20	14	62.5	23.06	27.93	87.99	70
				15	68.75	29.45	34.55	90.42	75
CHAR				16	75	37.61	42.73	92.65	80
				17	81.25	48.02	52.85	94.69	85
				18	87.5	61.32	65.37	96.59	90
				19	93.75	78.31	80.85	98.35	95
				20	100	100	100	100	100
		CHAR LIN		Linea	ır				
		CHAR EQ	1	Equal percentage (1/25)					
	Mode	CHAR EQ	2	Equal percentage (1/50)					
		CHAR QU		Quick Open					
	CHAR USI		र	User defined 17 points					
	Factory setting	CHAR LIN				-			
	<ul> <li>Run the special flow curve by us</li> <li>In addition to the above Lin typical flow characteristics, valve stroke position to ach</li> </ul>			, Equal user c e speci	percen an set t al flow o	itage, 0 he 4~2 curve c	0mA control.	orrespo	onding
	I o run this fur Steps			<b>U</b> 12 111	Descri		STRAC	mon	
USER DEF	*USR P0	Set the val	ve po	osition		•	t sianal	l is 4 m	A.
	*USE P1	Set the val					-		
	*USR P2	Set the val							
	*USR P3~16		ove steps for setting the valve position when the al is 7~19mA .						
	*USR P17	Set the val				ne inpu	t signal	l is 20 r	nA.
	1		•				•		

#### 6.7.3 DEVICE P

Submenu		Description	on		
Cusiliend			e set to Single or Double		
	manually.	manually.			
ACTU SNG	If the setting differs from the actuator type, the control characteristic may be degraded.				
	Mada	ACTU SNG	Single type		
	Mode	ACTU DbL	Double type		
	Eastery setting	TS800L	ACTU SNG		
	Factory setting	TS800R	ACTU DbL		
	Depending on the act manually.	tuator type, it must b	e set to Linear or Rotary		
			E		
ACTU LIN	If the setting differs fr be degraded.	om the actuator type	e, the control characteristic may		
	Mada	ACTU LIN	Linear type		
	Mode	ACTU ROT	Rotary type		
	Factory setting	TS800L	ACTU LIN		
		TS800R	ACTU ROT		
	When the input signal is higher than the set value, the valve is forced to open. This parameter is used to move the valve into its seat with the maximum force of the actuator.				
	Valve Stroke %				
	100				
		/			
FORCE OP					
	0 Force open set point %				
	0	Force close set poi	nt % 100		
	Range	0~100%			
	Factory setting	TS800L	100%		
	Note	TS800R When the	99.7% value set to 100%, this function is		
	not applied.				

When the input current signal is lower than the set value, the value is forced to close.           •         When the value is closed, residual pressure in the actuator chamber can be completely released.           Range         0-100%           Factory setting         0.3%           Note         When the value set to 0%, this function is not applied.           This function controls the operating speed of the value.         •           •         When the value set to 0%, this function is not applied.           DAMP         Range         0-500           Factory setting         0         When the value set to 0, this function is not applied.           DAMP         Range         0-500           Factory setting         0         Note           Value during the split range control.         For example, if the set value is 50%, 12mA corresponds to 0% of the value as 50%, 12mA corresponds to 0% of the value opening as shown on the right figure .         Imput Signal (mA)           SPLIT ZER         Set End point of the signal value during the split range control.         Imput Signal (mA)           Range         0-100.0%         20mA           SPLIT ZER         Set End point of the signal value is 50%, 12mA corresponds to 10% of the value opening as shown on the right figure .         Imput Signal (mA)           SPLIT END         Range         0-100.0%         Imput S						
Range       0-100%         Factory setting       0.3%         Note       When the value set to 0%, this function is not applied.         This function controls the operating speed of the valve.       • The higher the set value, the slower the operating speed of the valve.         • With this function, hunting problem in small actuator can be solved.       • With this function, hunting problem in small actuator can be solved.         DAMP       Range       0-500         Factory setting       0         Note       When the value set to 0, this function is not applied.         Set Zero point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       0         SPLIT ZER       Range       0-100.0%         Range       0-100.0%       Set Erd point of the signal value during the split range control.         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       Set Erd point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       Range       0-100.0%         Range       0-100.0%		<ul><li>forced to close.</li><li>When the valve is closed, residual pressure in the actuator chamber</li></ul>				
Factory setting       0.3%         Note       When the value set to 0%, this function is not applied.         This function controls the operating speed of the valve.       The higher the set value, the slower the operating speed of the valve.         OAMP       Range       0-500         Factory setting       0       0         Note       With this function, hunting problem in small actuator can be solved.         DAMP       Range       0-500         Factory setting       0       Note       applied.         Set Zero point of the signal value during the split range control.       100       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       90       100         SPLIT ZER       Range       0-100.0%       Factory setting       0.0%         SPLIT ZER       Set Earl point of the signal value during the split range control.       100       20mA         Range       0-100.0%       Factory setting       0.0%       100         SPLIT ZER       Set Earl point of the signal value during the split range control.       100       100         Range       0-100.0%       Factory setting       0.0%       100       100         Get Earl point of the signal value during the split range control.       100 <t< td=""><th>FORCE CL</th><td>Range</td><td>0~100%</td></t<>	FORCE CL	Range	0~100%			
Note         When the value set to 0%, this function is not applied.           This function controls the operating speed of the valve.         • The higher the set value, the slower the operating speed of the valve.           • With this function, hunting problem in small actuator can be solved.         • With this function, hunting problem in small actuator can be solved.           DAMP         Range         0-500           Factory setting         0           Note         When the value set to 0, this function is not applied.           Set Zero point of the signal value during the split range control.         100           For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .         0           Note         0.0%         20mA           Range         0-100.0%         20mA           Factory setting         0.0%         20mA           SPLIT ZER         Set End point of the signal value during the split range control.         100           Factory setting         0.0%         20mA           Set End point of the signal value during the split range control.         100           For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .         100           SPLIT END         Imput Signal (mA)         12mA           Range         0-100.0%         12mA						
This function controls the operating speed of the valve.         • The higher the set value, the slower the operating speed of the valve.         • With this function, hunting problem in small actuator can be solved.         Range       0-500         Factory setting       0         Note       When the value set to 0, this function is not applied.         Set Zero point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       100         SPLIT ZER       Imput Signal (mA)         Range       0-100.0%         Factory setting       0.0%         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the value opening as shown on the right figure .       100         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the value opening as shown on the right figure .       100         SPLIT END       Set End point of the signal value is 100% of the value opening as shown on the right figure .       100         Imput Signal (mA)       12mA         Imput Signal (mA)       12mA         Imput Signal (mA)       12mA						
Range     0-500       Factory setting     0       Note     When the value set to 0, this function is not applied.       Set Zero point of the signal value during the split range control.     100       For example, if the set value is 50%, 12mA corresponds to 0% of the value opening as shown on the right figure .     100       SPLIT ZER     9       Range     0~100.0%       Factory setting     0.0%       Set End point of the signal value during the split range control.     100       For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .     100       SPLIT END     8     9       SPLIT END     Range     0~100.0%		<ul><li>This function controls the operating speed of the valve.</li><li>The higher the set value, the slower the operating speed of the valve.</li></ul>				
Note       When the value set to 0, this function is not applied.         Set Zero point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       100         SPLIT ZER       99         Range       0~100.0%         Factory setting       0.0%         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT ZER       0.0%         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       100       100         Range       0~100.0%         Range       0~100.0%	DAMP	Range	0~500			
Note       applied.         Set Zero point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       100         SPLIT ZER       20mA         Range       0~100.0%         Factory setting       0.0%         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       Range       0~100.0%         Range       0~100.0%       12mA		Factory setting	0			
Set Zero point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 0% of the valve opening as shown on the right figure .       0         SPLIT ZER       0         Range       0~100.0%         Factory setting       0.0%         Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       100         SPLIT END       100         Range       0~100.0%         Range       100         Imput Signal (mA)       100         Imput Signal (mA)       100         Range       0~100.0%         Range       0~100.0%         Range       0~100.0%         Imput Signal (mA)       12mA         Imput Signal (mA)       12mA         Imput Signal (mA)       12mA         Imput Signal (mA)       12mA			,			
Set End point of the signal value during the split range control.       100         For example, if the set value is 50%, 12mA corresponds to 100% of the valve opening as shown on the right figure .       (%)         SPLIT END       (%)         Range       0~100.0%	SPLIT ZER	value during the split range For example, if the set value 50%, 12mA corresponds to of the valve opening as sho on the right figure .	e is 0% wn % avg vr 0 12mA lnput Signal (mA)			
value during the split range control.         For example, if the set value is         50%, 12mA corresponds to 100%         of the valve opening as shown         on the right figure .         SPLIT END         Range       0~100.0%		Factory setting	0.0%			
	SPLIT END	value during the split range For example, if the set value 50%, 12mA corresponds to of the valve opening as sho	e is 100% wn % e is 100% wn % e is 100% wn 100% 0 4mA 12mA			
Factory setting100.0%		Range	0~100.0%			
		Factory setting	100.0%			

	This parameter corrects th opening.	ne error betw	een LCI	) value	and actual valve	
	opening.		ICE			
COMPENSA	This function should only be used with Linear type products and Rotary products must be set to 0%.					
	Range	-50.0~50.0%				
	Fastern setting	TS800L(	Linear ty	ype) 3.0%		
	Factory setting	TS800R	(Rotary t	ype)	0.0%	
	Change the action type of	the valve.				
	Reverse Actio	n		Dir	ect Action	
ACT NORM	Valve Stroke%	nput Signal mA	Valve Stru 100 0 20m.		Input Signal mA 4mA	
	Mode ACT NOR		Reverse Action			
		ACT REVE		Direct Action		
	Factory setting	ACT NOR	М			
	Set the feedback signal from the positioner can be output at the same percentage as the valve stroke, or the opposite percentage.					
	Normal			Reverse		
OUT NORM	100 (%) 0 4mA Output Signal (mA)	20mA	Valve Stroke (%)	0 20mA	4mA utput Signal (mA)	
	Mode	OUT NORM		Normal action		
		OUT REVE		Reverse action		
	Factory setting Adjusts the valve opening communication signal.	OUT NORI		se or di	rection of HART	
HT NORMR		HT NORM			t action	
	Mode	HT REVER			erse action	
	Factory setting	HT NORM	D			

	Display the valve o	Display the valve opening value on LCD in direct/reverse direction.		
	Mode	Description		
DSP NORM	DSP NORM	Displayed 0% on LCD when the valve is 0%, and displayed 100% on LCD when the valve is 100%.		
	DSP REVE	Displayed 100% on LCD when the valve is 0%, and displayed 0% on LCD when the valve is 100%.		
	Factory setting	DSP NORM		

#### 6.7.4 INFOMATN

You can find the following information through Submenu.

Submenu	Description				
FIRM VER	Display firmware version of the product.				
DEVI REV	Display the version of device.				
HART VER	Display the version of HART communication.				
POLL ADD	Display Polling address of the device in HART communication.				
	Display the accumulated total travel distance of the valve after the positioner has been used. (Unit: K%)				
TRAVEL K	One full travel distance from full close to full open means 100% = 0.001K% For example, if the travel value is 1K%, this means that the valve has moved 1000 stroke percentages.				
OP TIME	Display the time that takes from the valve fully close to fully open during Auto calibration. Unit : Second				
CL TIME	Display the time that takes from the valve fully open to fully close during Auto calibration. Unit : Second				
TEMPERAT	Check the current ambient temperature of the positioner through the built-in temperature sensor.				
TEMP MAX	Display the recorded highest ambient temperature value after using the product.				
TEMP MIN	Display the recorded lowest ambient temperature value after using the product.				

#### 6.7.5 DIAGNOST

Submenu	Description				
ERR CODE		e of the product. e error code to resolve the problem. e refer to Page 51.			
		ction checks the installation status of the product, internal ube connection, etc.			
	Error code	Description			
	PNEUMATIC	No pneumatic output to OUT port.			
	POTENMTR	Main shaft gear and Potentiometer gear are dislocated due to external shocks, etc.			
АИТО СНК	SIZE ANGLE	Display rotation angle of the lever of the product. Installation problems do not occur frequently for Rotar product. However, for linear product, the angle of the product may be bigger or less than the effective angle(60°) depending on bracket and the position of lever connection. If displayed number is less than 40° please refer to page 15-17 to correctly install the product again.			
	COMPENSATE	Display the optimal compensation value based on the current rotation angle.			
	Run PST function	according to the following PST CFG configuration.			
PST RUN	What is PST?	Partial stroke testing (or PST), within the range of not affecting to the flow process, PST prevents the valve stem from sticking by moving the valve finely according to the set value and the period. In case of emergency, it can make the valve operate normally.			
PST CFG	Set necessary iter Submenu of PST				

\_

	Outerstand		Description		
	Submenu		Description		
	0P POINT	Valve initial pos	alve position for PST to start. sition must be within ±1% from " <b>0S</b> wait until this condition is satisfied.		
		Default value	100%		
		Range	0~100%		
		Set 1st target po	osition of PST.		
	1S POINT	Default value	90%		
		Range	0~100%		
		Set 2nd target p	position of PST.		
	2N POINT	Default value	80%		
		Range	0~100%		
		Set the waiting t before the seco	time after the first PST is end and ond PST start.		
	INTERVAL	Default value	20 (Seconds)		
		Range	1~100 (Seconds)		
	LATENCY	Set the waiting time from " <b>1S POINT</b> " to " <b>2N POINT</b> " start. After reaching the first target point " <b>1S POINT</b> ", return to the initial position, wait for " <b>LATENCY</b> " time specified by the user, and then move to the second " <b>2S POINT</b> " target point again.			
		Default value	10 (Seconds)		
		Range	1~100 (Seconds)		
	LMT TIME	Set the time allowed to reach the target point. If the time to reach the target value during the PST execution exceeds " <b>LMT TIME</b> " time or there is no movement, PST is considered to have failed and PST is immediately interrupted.			
		Default value	50 (Seconds)		
		Range	1~100 (Seconds)		
		In PST process, if the valve position exceeds "EMERGNCY" set value, PST function is stopped.			
	EMERGNCY	Default value	15%		
		Range	0~100%		
PST REDy	Check PST function execution result value. The following information is displayed on LCD based on the sand the execution results. See the table below to confirm PST result information.				
	Result Value	PST REDy	Ready to run PST.		
		PST SUCS	PST success.		

		PST TOUT	"LMT TIME" failed to reach the target
			value within the set time value range.
		PST FIXD	Valve has no action.
		PST DOUT	Exceed the target value more than 1%.
		PST EMRG	When allowable range of valve movement, i.e. "EMERGENCY" value is exceeded.
		ned "ON", and I	following conditions are satisfied, the _CD displayed A1 symbol. peration.
			A1 A2 + - + -
AL1 NONE		9~30V DC	
		AL1 URGT	When the product has a serious problem (If priority value of error code is "0") (Refer to page 51)
	Mode	AL1 PRI 1	When there is a potential problem. (If priority value of error code is "1") (Refer to page 51)
	Mode	AL1 PRI 1 AL1 F_CL	When there is a potential problem. (If priority value of error code is "1")
	Mode		When there is a potential problem. (If priority value of error code is "1") (Refer to page 51)
	Mode	AL1 F_CL	When there is a potential problem. (If priority value of error code is "1") (Refer to page 51) When the valve is fully closed.
	Mode Factory setting	AL1 F_CL AL1 F_OP	When there is a potential problem. (If priority value of error code is "1") (Refer to page 51) When the valve is fully closed. When the valve is fully opened.
AL2 NONE	Factory setting Set Alarm 2 According to the s	AL1 F_CL AL1 F_OP AL1 NONE AL1 NONE AL1 NONE et value, If the fined "ON", and I	When there is a potential problem. (If priority value of error code is "1") (Refer to page 51) When the valve is fully closed. When the valve is fully opened. Disable this alarm function
AL2 NONE	Factory setting Set Alarm 2 According to the s alarm circuit is turn	AL1 F_CL AL1 F_OP AL1 NONE AL1 NONE AL1 NONE et value, If the fined "ON", and I luring normal op	When there is a potential problem. (If priority value of error code is "1") (Refer to page 51) When the valve is fully closed. When the valve is fully opened. Disable this alarm function

### 6.7.6 EMERGNCy

Submenu	Description			
PASSWORD	Must put a password to enter this menu. The password is set at the factory and cannot be changed by the user.			
	Factory setting	Press <b>UP &gt; ENTER &gt; DOWN &gt; UP</b> button sequentially. (1321 on LCD)		
	Set the position of the valve to be moved when an abnormality of the positioner is detected. (If priority value of error code is "0") (refer to page 51)			
		EMGy NON	Do not take any action.	
EMGY NON		EMGy OP	Open the valve fully.	
	Mode	EMGy CL	Close the valve fully.	
		EMGy STP	Stop the valve operation.	
	Factory setting	EMGy NON		
FULL OP	Open the valve fully by manual regardless of the input signal.			
FULL CL	Close the valve fully by manual regardless of the input signal.			
STOP	Maintain the present valve position regardless of the input signal.			
UNLOCK	It locks to prevent changing all parameter values. When set to " <b>LOCK</b> ", all commands such as Auto calibration, PID changes, and parameter values settings cannot be changed.			
	Mode	LOCK	Lock the program	
		UNLOCK	Unlock the program	
	Factory setting	UNLOCK		

## 7 Error code and Troubleshooting

### 7.1 Error code during Auto calibration

- Error code as below is displayed on LCD if an error occurs during Auto calibration.
- Check the error code and refer to the table below to solve the problem.

No	Error Code	Cause	Solution	
1	STEP0 V0	Displayed when the valve does not stop after a long period of time when the data is measured to detect the first stop of the valve during auto calibration. And it is mainly caused by damage to Main board.	• Replace Main PCB.	
2	STEP1 PZ	Displayed when Zero point is lower than allowable range.	<ul> <li>Check the status of the positioner installation or reinstall the positioner.</li> <li>Set initial angle (Zero point) of the lever higher than the current status.</li> </ul>	
3	STEP2 PE	Displayed when End point is higher than allowable range.	<ul> <li>Check the installation status of the positioner or reinstall the positioner.</li> <li>Set final angle (End point) of the lever lower than the current status.</li> </ul>	
4	ACT TYPE	Displayed when Zero point and End point of the lever are too close or equal.	<ul> <li>Check the status of supply air.</li> <li>Unplug the potentiometer cable in the positioner and reconnect it to Main board.</li> <li>Check the status of feedback lever installation. And set the operation angle that between initial angle(Zero point) and final angle(End point) over 40 degree.</li> <li>Replace Main PCB.</li> </ul>	
5	STEP3 CT	Displayed when Close time is too long during auto calibration.	<ul> <li>Check the status of feedback lever installation.</li> <li>If Zero point of the valve changes, please conduct auto calibration 2~3 times.</li> <li>If the actuator size is too big, please set TbL value as TbL 4 LLS and conduct auto calibration again. (Refer to page37)</li> </ul>	

# Smart valve positioner TS800/TS805 Series

6	STEP4 OT	Displayed when Open time is too long during auto calibration.	<ul> <li>Check the status of feedback lever installation.</li> <li>If the actuator size is too big, please set TbL value as TbL 4 LLS and conduct auto calibration again. (Refer to page37)</li> </ul>
7	STEP5 BL	Displayed when LOW BIAS value is not found within the allowed time.	<ul> <li>Check the status of supply air.</li> <li>If Torque motor of the positioner is damaged, please replace Torque motor.</li> <li>Check the status of feedback lever installation.</li> </ul>
8	STEP6 BH	Displayed when HIGH BIAS value is not found within the allowed time.	<ul> <li>Check the status of supply air.</li> <li>If Torque motor of the positioner is damaged, please replace Torque motor.</li> <li>Check the status of feedback lever installation.</li> </ul>
9	PID TBLE	Displayed when PID Table memory of Main PCB is damaged.	Replace Main PCB.
10	STEP7 MX	Displayed when the positioner can't find the accurate position due to friction of the actuator is too big.	• Change TbL value as TbL 3 LS to minimize the friction of the valve stem and conduct auto calibration again. (Refer to page37)
11	ERR	Displayed when auto calibration failed due to other unknown reasons.	Replace the positioner.

## 7.2 Error code during operation

- If there is a problem during the operation, please enter "ERR CODE" which is Submenu of "DIAGNOST" to check the error code.
- Check the error code and refer to the table below to solve the problem.

No	Code	priority	Cause	Solution
1	L	1	Valve End point is set too high	<ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul>
2	к	1	Valve Zero point is set too low	<ul> <li>Check whether the positioner is installed too high or low.</li> <li>Check whether the positioner is installed too far from the actuator. (Check the angle of use)</li> <li>Check the potentiometer gear and main gear are out of position. (The cause of the problem is strong vibration or external shock).</li> </ul>
3	J	1	Valve End and Zero points are set too close. (Use angle is too small)	<ul> <li>Increase the angle of use by repositioning the positioner closer to the actuator.</li> </ul>
4	I	1	Input current is below 3.8mA	Check input current signal
5	н	1	Input current is over 22mA	Check input current signal
6	G	1	BIAS value exceeds limit	<ul> <li>Run Auto-Calibration again (Accuracy is significantly reduced when used without auto-calibration)</li> </ul>
7	F	1	Ambient temperature is too high	Check ambient temperature
8	E	1	Ambient temperature is too low	Check ambient temperature
9	D	1	Used over 100,000 cycles	Check positioner regularly
10	С	0	Used over 500,000 cycles	Check positioner regularly
11	В	0	Used over 1million cycles	Replace positioner



# Tissin Co.,Ltd.

201-1105, No 397, Seokcheon-ro, Ojeong-gu, Bucheon-si, Gyeonggi-do, Korea 14449 Tel : +82-32-624-4573, Fax : +82-32-624-4574 www.tissin.co.kr