

: How to update window CE


LSIS QUICK GUIDE

XP-Builder 1.30


2013.01.01

How to update window CE

(a) On the screen of Windows CE, touch or click a mouse underneath the screen as follows.




Touch the grey part.




Select [Start → Programs → Windows Explorer].

(b) In windows Explorer




Move into the folder named FlashDisk.



Replace the old 'HMIStartup.Ink' file with the modified 'HMIStartup.Ink' file.

When you turn off and on your XGT Panel, your program will be started.

How to update window CE



Please delete selected folder, then double click 'HMISStartup'

(c) If you can't see the normal operation, you should replace the old 'LSISProduct' folder to this file.
(C:\Program Files\LSIS\WXP-Builder 1.30\WXP-Runtime\WGENERAL)

When you turn off and on your XGT Panel, your program will be started.