PAN/TILT DRIVE TYPE

REMOTE CONTROLLER



V2.0

CONTENTS

FEATURES	3
DRAWING	4
CABLE CONNECTION	5
DVR PROTOCOL	6
BUTTON KEY	7
ESTABLISHMENT	10
SPECIFICATION	11



CAUTION

Risk Of Electric Shock Do Not Open



- •The dome camera must be installed by qualified service personnel in accordance with all local and federal electrical and building codes.
- •Do not use this product in the place where may occur fire, electric shock or injury to persons.
- •Do not use this product near water such as near a bathtub, washbowl, kitchen sink, laundry tub...etc.
- •Do not install this products in the place where is an unstable cart, table that may fall, causing serious injury to a child or adult.
- •Do not put objects of any kind into this product

FEATURES

As multi-function of CCTV controller, IR/RC-200 can control CCTV camera, PAN&Tilt driver and DVR by RS-485(RS-422,RS-232) interface.

Multi protocol available

IR/RC-200 can be set kinds of cameras which have different protocols not only WONWOO and PELCO-D but also various other protocols.

Preset

Up to 240 programmable preset function.

Group

Up to 16 programmable group function.

Tour

Up to 16 programmable Tour consisting of Preset, Group and

Swing functions.

Swing

Repeatedly pan & tilt operate between two positions.

Pattern

The pattern records that user controlled the selected camera. Up to four patterns can be stored.

Monitor Setting

Selectable DVR & Monitor screen.

Menu

Camera OSD and Menu setting.

Speed Control

Control camera speed as user pleases.

Connectable with DVR and Key Board

IR/RC-200 is connectable with DVR and key board controller to control speed dome camera. (But , This functions is available when Keyboard match with DVR protocol.)


Display


The window of IR-200 can show the function name and operating state.

Interface convert.

IR-200 can be converted to RS-232C and RS-485.


DRAWING







CABLE Connection



Picture 1. picture 2.

Number	Definition		
1	DATA GND (Red)		
2	D + (Black)		
3	D - (White)		
4	DVR - (Green)		
5	DVR + (Yellow)		
6	DVR GND (Blue)		


RS-485 SET UP RS-232C SET UP

CAMERA CAMERA INPUT: INPUT:No.2,3

DVR OUTPUT : DVR OUTPUT:

No. 4,5

Connect RS485



Picture 2 shows IR/RC-200 and a camera can be connected with RS-485 and RS-232 both, and DVR can be done by same way.

DVR PROTOCOL

MONITOR CONTROL PROTOCOL

Format

Interface speed: 9600bps

Data: 8Bit 1Start 2Stop

STX	DVR	CHANNEL	CHKSUM
	NUMBER	CHANNEL	
ААН		00H ~ 0FH	
	00H ~ 0FH	(MAX 16)	AAH + DVR
	(MAX 16)	All chanel display	NUMBER + CHANNEL
		Mode	

1) STX: AA(Hex)

2) DVR NUMBER: 00H ~0FH is Hex value of 16 DVR.

3) CHANNEL :Hex value of 16 channel(00H ~0FH)DVR

4) CHKSUM: STX + DVR + CHANNEL=(Low 1Byte)

Example

1) Channel No.2 of No.1 DVR

AAH, 01H, 02H, ADh

2) All channel of No.2 DVR

AAH, 01H, FFH, AAH

3) Channel No.12 of No.15 DVR


AAH, 0FH, 0CH, 05H

4) All channel of No.15 DVR

AAH, 0FH, FFH, B8H

Button Key

Remote controller



Please refer to the manual of JCN series to get the detail. Below is shortcut keys.

1 Select protocol

LG-CAM

LPT-A100

DRX502A(Wonwoo): 880 MENU PELCO 'D' : 881 + ← MENU SCAN - DOME : 883 +0 MENII GC-655-CAM : 884 +C LG-DOME : 885 +

: 886 +

: 887 +

IR/RC-200 can be set kinds of cameras which have different protocols by using shortcut keys

Example

Model	ADDRESS	Remote controller setting	Shortcut key
JCN-201	01	1+CAM key => 880 + MENU key	1+CAM => wonwoo protocol
LPT-A100	02	2+CAM key => 887 + MENU key	2+CAM => LPT-A100 protocol
LG-DOME	03	3+CAM key => 885 + MENU key	3+CAM =>LG-DOME protocol

2 CAMERA ID : Set the camera number + C

С Confirm CAMERA ID:

3 MONITOR CHANNEL select: Set the monitor number +

Confirm MONITOR CHANNEL: M

(MENU Go into TOTAL MENU: 999+

P-SET 5 PRESET: set the preset number +

P-SET) (MENU PRESET MENU:

PRESET number setting: P-SET +Assigned number. MENU

6 GROUP Set the group number +

GROUP


GROUP MENU: GROUP + No+ (MENU

GROUP number setting Assigned number + MENU **ĠROUP**


: Tour number setting **TOUR** TOUR + (MENU TOUR TOUR MENU + Assigned number + MENU TOUR TOUR number setting: (PELCO 'D' has no above function) Assigned number is kind of shortcut number of PRESET/GROUP/SWING that makes these functions start without any additional operating. 7 SWING: Set the swing number + SWING SWING MENU: (SWING) + Swing number + MENU) + Assigned number + MENU SWING number setting : SWING (In wonwoo protocol, only number '0' available) **PATTERN** 8 PATTERN : Set the pattern number **PATTERN** PATTERN MENU: MENU) + Assigned number + MENU PATTERN number setting **PATTERN** (J-PAN has no this function.) 9 If you want to stop the preset, group, tour and swing functions, press the preset, group, tour, cam and swing keys. (If you press the rest of keys (not above keys), the moving will not stop.) 10 If you want to remove the selected number, just press the MENU key and reset it by pressing number '0' 11 Select the KEYBOARD DRX503A(Wonwoo): No. 800 + MENU No. 801 + PELCO 'D' 12 SHIFT Key If you want to move speedily, push the SHIFT key while you move by pushing the direction key. When you just push the direction key, it will move with normal speed.

Establishment

IR-200 & Keyboard Control



DVR & IR-200 Control



SPECIFICATION

Specification					
ir-200 Power		DC 12V 500mA			
	Front Case	ABS			
Material	Back Cover	ABS			
	Remote Housing	ABS			
	Window	ACRYL			
Color		Silver			
Size		W 82 × H 100 × D 105			
Weight		130g			
		Interface	Wonwoo	9600bps	
	RS -485(2Wire)	speed	Pelco-d	2400bps	
Interface	RS-232C	DATA		8bit	
	Choice	Start Bit		1bit	
		Stop Bit		1bit	
RC-200 POWER		DC 3V, AAA Size Battery			
Bu	Button Key 29 Key		29 Key		
Availa	Available distance 20 M		20 M		
Remote controller		ABS			
Material	Button Key	Rubber			
Color		Silver			
Size			W 45 x H 165 x D 20		
Weight		100g			