

# DAEHAN SENSOR



Capacitance Type Level Sensor  
with level switch

DC – Series

Level Switch with Contact – Output

Product Name

DC – 103



ISO 9001 인증업체

---

1993 DAEHAN SENSOR CO., LTD.  
All rights reserved

# Table of Contents

1. Introduction .....	3
2. Features .....	3
3. Specification .....	3
4. Installation .....	4
5. Calibration & Setting .....	4
6. Wiring Connection .....	5
7. Check Point Before A/S .....	6

## SPECIFICATIONS

Media : Only Liquid

Wiring : Input - 2 wire

Wiring : Output - 2 wire


Input Voltage : DC 5V

Output Signal : DC 5V

Temperature : A, M, B

Pressure : A, T, M

Material : Stem - P.P



## Introduction

The outage capacity type radio frequency level sensor is detected according to the change of outage formed between the earth electrodes when the measuring electrode and the electrode area are in the air and in the material.

This change alters the electrical control signal of the main unit that it is possible to receive the relay output point of contract.

## Features

This sensor is for indicating liquid level and alarming to control.

It is easy to install so that generally used.

It is able to use in chemical tanks.


## Installation

As shown in the picture, it is installed and using.


Check if the flanges specification (or socket) match between tank and product.

Insert a probe into the tank.

Connect wiring between sensor contact terminals and controller.



## © Installation Caution ©



You should pay attention to the phenomenon when using for adhesive liquid, as shown in the picture.

A malfunction is caused by the liquid attached to the sensing part.


## Calibration

DC-103 sensor is custom-made sensor.

There is no way for you to alter setting.

Wiring Connection

Wiring to a DC-Power Supply



## Check & A/S

The input voltage is normal?

: Check if the input of AC 220V/110V, is normally supplying.

The wiring is correct?

: Check the connect the wire short-circuit and / or poor contact.

The state of sensor is normal?

: Check if water or liquid exists inside of the sensor.

Head Office

94-2, Yongdap-dong, Seongdong-gu, Seoul, Korea

R&D Office

2-71, Jeonong-dong, Dongdaemun-gu, Seoul, Korea

Tel : 02-2213-9888(代) Fax : 02-2245-3482

e.mail : master@dh34.com Domain : www.dh34.com