


#### www.iolink.co.kr

# R16G-F Series 16Points, OMRON G6B Relay mounted, Detachable Terminal Block

# User's Guide





Thank you for purchasing product of SAMWON ACT.

Please check model of product that you purchase first, and read this manual prior to use it.

## Caution for Safety

⚠ Caution Case that results in serious damage in human body or equipment, and fire if user handles this equipment wrongly

Marning Case that results in slight damage in human body or equipment, and fire if user handles this equipment wrongly

# 

- 1. Do Not use other voltage except appointed voltage. It may be the cause of fire or damage of equipment.
- Use it within nominal voltage and current which are marked on load.It may be the cause of fire or damage of equipment.
- Check COMMON polarity of using controller (PLC, etc) first, and then select proper product. It may be the cause of fire or damage of this equipment and user's.
- 1) COMMON Polarity of controller is '+' (NPN TYPE): R16G-NS5A-F
- 2) COMMON Polarity of controller is '-' (PNP TYPE): R16G-PS5A-F
- 4. Please make sure to check the internal wiring diagram of the terminal block and the arrangement of the controller PIN (terminal) when making the connection cable between the controller (PLC etc.). It may be the cause of malfunction or damage of this equipment and user's.
- \*\* The connection cable for PLC of various makers is provided by us. Please refer to the catalogue or contact Head or branch office if you need more detail models and specifications.

### 

- Plug or unplug power line and/or connector for signal after making sure to shut off power so as that it is prevented to be damaged or malfunctioned.
- Read this user's guide which is attached to product, and check product's performance, specification, operation pattern, signal, and how to handle prior to use. Keep user's guide please.
- When wiring the terminal block, please tighten it with the specified torque using the appropriate tool.If it is outside of this range torque, it may cause malfunction due to breakage or looseness of tightening surface terminal.
- 4. When replacing a relay, check how to replace the relay on the back of the manual before using it.

## Model Configuration

	Model	Installation Relay	IO Point(s)	Coil Rate voltage	Common		Interface		Dimensions	Mounting
					Coil	Contact	Coil	Contact	Dimensions	method
	R16G-NS5A-F	OMRON G6B-1174P	16Point (1a * 16)	24V DC	NPN ⊕com	Individual	Connector MIL-C-	Screw Terminal	174.0 * 70	DIN Rail (Channel)
	R16G-PS5A-F	-FD-US DC24V			PNP -com	Com.	83503 20Pin	7,4mm Pitch 40Pole		


#### G6B Relay Specification

	Item	G6B-1174P-FD-US DC24V		
	Arrangement	SPST-NO (1a)		
Contact	Nominal switching capacity (resistive load)	5A 250V AC / 5A 30V DC		
Contact	Max, switching current	5A		
	Max, switching voltage	380V AC / 125V DC		
	Nominal voltage	24V DC		
	Pick-up Voltage	70% max of Rated voltage		
Coil	Drop-out Voltage	10% min of Rated voltage		
	Coil resistance	2,880 Ω		
	Nominal operating power	Approx, 200mW		
Surge voltage	ge between contact and coil	6,000V		
Initial break	down voltage between contact and coil	AC 3,000V 50/60Hz 1min		
Country of o	origin	JAPAN		

#### Material/Specification


Case	Modified PPO			
Protective cover	Polycarbonate			
P.C.B	Epoxy 1,6t / 2oz			
Applicable wire	AWG22~16 (1.5mm²/MAX)			
Terminal Screw	M3.5 X 8L			
Screw torque	7~8Kgf • cm (0,68~0,78 N • m)			
Ambient temperature	−10°C $\sim$ +50°C (No condensation)			

#### Applicable crimp terminal






• R16G-NS5A-F ⊕ com




#### Dimension

• R16G-PS5A-F COM



# Wiring Diagram


#### Wiring Diagram



- $\ensuremath{\mathbb{X}}$  The above specifications are subject to change without notice.
- \* Please contact HQ or branch office where you purchased product for A/S of this product or technique,

# Major products

- Relay terminal 1, 2, 4, 6, 8, 16, 32point
- Interface terminal 20, 24, 26, 34, 40, 50, 57, 40 x 2pole
- PLC I/O Connecting cables MITSUBISHI, LSIS, CIMON, OMRON, FUJI, YOKOGAWA, HITACHI, SIEMENS, AB, etc.
- Servo Connecting cables Encoder cable, Power cable, Motion cable / MITSUBISHI, YASKAWA, OMRON, PANASONIC, , LSIS, SAMSUNG, etc.
- Wiring harness / Special cable assembly



- HQ: 47035, 28, Daedong-ro, Sasang-gu, Busan, Korea TEL: (051)320-7777 FAX: (051)312-2233
- SEOUL Office: 501, Iljik-dong, Gwangmyeong-si, Gyeonggi-do
- TEL: (02)837-2230 FAX: (02)837-2226